


26-30 FRONT AXLE - Freewheel Clutch Assembly, Differential Carrier



INSPECTION

FREEWHEEL ENGAGE SWITCH

Shaft (switch) position	Terminal No. 1	Terminal No. 2
Pressed (ON)		
Released (OFF)		