



SERVICE SCHEDULE

**PAJERO**

2.8DT, 3.0 12V, 3.0 24V & 3.5 24V



**Service**

SERVICE INTERVALS ARE 10 000 Km OR 6 MONTHS WHICHEVER OCCURS FIRST.  
(LABOUR HOURS AND INTERVAL SUMMARY ON REVERSE SIDE OF SHEET)

**Service**

|                  |  |                  |  |
|------------------|--|------------------|--|
| Date             |  | Service Required |  |
| Registration No. |  | Model            |  |
| Speedo Reading   |  | Repair Order No. |  |

**OPERATIONS INSIDE THE ENGINE COMPARTMENT**

|  | First                       | A | B | C |
|--|-----------------------------|---|---|---|
| Check V-belt for cracks, fraying, wear and adjust its tension  | I                           |   | I | I |
| Check condition of distributor spark advancer, cap and rotor   |                             |   |   | I |
| Check ignition cables for damage   |                             |   |   | I |
| Check vacuum pump oil hoses for damage (Diesel)  |                             |   | I | I |
| Check intake air hoses and turbo oil hoses for damage (Diesel)   |                             |   |   | I |
| Replace engine timing belt   | <b>Every 100,000 km</b>     |   |   |   |
| Check operation of crankcase emission control system (including crankcase ventilation filter in air cleaner) |                             |   |   | I |
| Replace spark plugs  | Leaded fuel                 | I | R | R |
|  | Unleaded fuel               | I | I | R |
| Check radiator hoses for damage, and proper connection   |                             |   |   | I |
| Check engine coolant level in reservoir  | I                           |   | I | I |
| Change engine coolant  |                             |   |   | R |
| Check air cleaner element for clogging and damage  | Normal usage                |   | I | I |
|  | Severe usage                | I | I | I |
|  | Replace air cleaner element |   |   | R |
| Check fluid level in automatic transmission  |                             |   | I | I |
| Change automatic transmission fluid (including transfer)   |                             |   |   | R |
| Check fluid level in brake reservoir   | I                           | I | I | I |
| Change brake fluid   |                             |   |   | R |
| Check brake pedal and clutch pedal for free play   | I                           | I | I | I |
| Check battery electrolyte level  | I                           | I | I | I |
| Check injection nozzle (if exhaust gases include black smoke and lack of power) (Diesel)                     | <b>Every 30 000km</b>       |   |   |   |
| Replace fuel filter (except filter in tank) (Diesel)   |                             |   | R | R |

**OPERATIONS UNDER THE VEHICLE**

|   | First        | A | B | C |
|---|--------------|---|---|---|
| Check suspension system for damage and looseness  | I            |   | I | I |
| Check suspension arm ball joints for play, and dust covers for damage                   |              |   | I | I |
| Lubricate suspension arm, steering linkage and propeller shaft with lubrication fitting |              |   | L | L |
| Check drive shaft boots for damage  | Normal usage |   | I | I |
|   | Severe usage | I | I | I |
| Check steering linkage for damage and loose connections (including seals and boots)     |              |   | I | I |
| Check gear oil level in manual transmission (including transfer case)                   |              |   |   | R |
| Change gear oil in manual transmission (including transfer case)                        |              |   |   | R |
| Check gear oil level in rear axle   |              |   | I | I |
| Change gear oil in rear axle  | Normal usage |   |   | I |
|   | Severe usage |   | I | I |
| Check parking brake stroke and play   | I            |   | I | I |
| Check exhaust pipe connections for gas leakage and check pipe installation              |              |   | I | I |

**OPERATIONS OUTSIDE THE VEHICLE**

|   | First                  | A                     | B | C |
|---|------------------------|-----------------------|---|---|
| Check wheel alignment                       |                        |                       | I | I |
| Check front wheel bearings for play         | <b>Every 60 000 km</b> |                       |   |   |
| Check brake hoses and pipes for leakage     |                        |                       | I | I |
| Check brake pads and disks for wear         | Normal usage           |                       | I | I |
|   | Severe usage           | <b>Every 5 000 km</b> |   |   |
| Check brake shoe linings and drums for wear |                        |                       | I | I |
| Check fuel hoses and pipes for leakage      | Normal usage           |                       | I | I |
|   | Severe usage           | I                     | I | I |

**OPERATIONS AFTER ENGINE IS WARMED UP**

|  | First                 | A                     | B | C |
|--|-----------------------|-----------------------|---|---|
| Change engine oil and oil filter (Petrol)                | Normal usage          | R                     | R | R |
|  | Severe usage          | <b>Every 5 000 km</b> |   |   |
| Change engine oil (Diesel)                               | Normal usage          | <b>Every 5 000 km</b> |   |   |
|  | Severe usage          | <b>Every 3 000 km</b> |   |   |
| Change engine oil filter (Diesel)                        | Normal usage          | R                     | R | R |
|  | Severe usage          | <b>Every 6 000 km</b> |   |   |
| Check engine idling speed and CO concentration (Petrol)  | I                     |                       | I | I |
| Check engine idling speed (Diesel)                       | I                     |                       | I | I |
| Check ignition timing (Petrol)                           |                       |                       | I | I |
| Check crankcase ventilation hoses (Petrol)               |                       |                       |   | I |
| Check exhaust gas recirculation (E.G.R.) system (Petrol) |                       |                       | I | I |
| Check valve clearances (Diesel)                          | I                     |                       | I | I |
| Check body condition for damage/corrosion                | <b>Every 6 months</b> |                       |   |   |
| Road Test  | I                     |                       | I | I |

EXPLANATION OF ABBREVIATIONS: I - Inspect. R - Replace. L - Lubricate.